



Installations-Anleitung für SMS-Alarmierung-Tool



Download - WAP-Server:

„Permanent“

<http://www.nagl-elektronik.at/wap/>



Do not shut-off the ringtones.



Konfig – Blue.Box II

International

no Flash

Persons					
No	Rank	Last Name	First Name	Phone Number	Flash-SMS
1		Mustermann	Max	+43 664 1234567	